

Chromaticity Measurements using Phase Modulated RF and Vector Signal Analyzers



Dave McGinnis

mcginnis@fnal.gov

Fermilab

CERN PLL Workshop

June 10-11, 2002

Work based on PBAR Note 656

See: http://www-bdnew.fnal.gov/pbar/documents/pbarnotes/pdf_files/PB656.PDF




Chromaticity and Tune Measurements in the TEVATRON

- The betatron motion is excited by the “residual noise” of the TEVATRON (power supply ripple, kickers, vibrations, RF noise, etc.)
- Betatron signal is measured with stripline pickups resonant at 21 MHz (harmonic 441).
 - ❑ The signal is down converted to baseband with a sine wave at harmonic 441
 - ❑ The signal is analyzed with vector signal analyzers (FFT Box)
- The TEVATRON operates with a rather large chromaticity (>6) to combat head-tail instabilities.
 - ❑ The TEVATRON does not have transverse dampers in collider mode because of the emittance growth due to the noise of the dampers
 - ❑ Because of the large chromaticity, there are typically 5-10 synchrotron lines modulating the betatron lines
 - Revolution Frequency = 47 kHz
 - Betatron Frequency = 20 kHz
 - Synchrotron Frequency = 80 Hz (at injection)




Chromaticity and Tune Measurements in the TEVATRON

- To measure the chromaticity, the beam energy is changed by changing the RF frequency.
 - The beam energy is changed by about $\pm 0.03\%$ so that an appreciable shift in betatron tune is observed.
 - The measurement of betatron tune is complicated by the large amount of synchrotron lines.



f RF Phase Modulation Method for Measuring the Chromaticity in the TEVATRON



- Fermilab is currently investigating a RF phase modulation technique for measuring the chromaticity in the TEVATRON
- In this method, the beam energy is modulated at a very low frequency (\ll synchrotron frequency) by phase shifting the RF drive to the cavities.
- The signal is analyzed by a vector signal analyzer that uses digital PM demodulation algorithms.



Betatron Motion with Phase Modulated RF

- RF Phase modulation

$$\phi_{\text{rf}} = \omega_{\text{rf}} t + \Delta\phi_{\text{rf}} \sin(\Omega_{\text{mod}} t)$$

- Energy modulation

$$\frac{\Delta pc(t)}{pc} = -\frac{1}{\eta\omega_r} \left(\Omega_{\text{mod}} \frac{\Delta\phi_{\text{rf}}}{h} \cos(\Omega_{\text{mod}} t) + \underbrace{\Omega_s}_{\text{Synchrotron amplitude}} \underbrace{\Delta\phi_s}_{\text{Synchrotron frequency}} \cos(\Omega_s t + \theta_s) \right)$$

Synchrotron motion

- Betatron frequency at the k^{th} harmonic

$$\frac{d\phi_{k\pm}}{dt} = (k \pm Q_o) \omega_r + \left(k \pm Q_o \mp \frac{\chi}{\eta} \right) \frac{\Omega_{\text{mod}} \Delta\phi_{\text{rf}}}{h} \cos(\Omega_{\text{mod}} t) + \left(k \pm Q_o \mp \frac{\chi}{\eta} \right) \Omega_s \Delta\phi_s \cos(\Omega_s t)$$

where Q_o is the fractional tune and χ is the chromaticity



Beam Current Spectrum with Phase Modulated RF

$$I_{\Delta} = \frac{\omega_r q_b}{2} \frac{A}{\sqrt{\epsilon_{\max}}} \sum_{k=0}^{\infty} C_k \sum_{n=-\infty}^{\infty} \sum_{m=-\infty}^{\infty} J_m(Y_+) J_n(Z_+) \cos(\omega_{k,m,n}^+ t + \psi_+) \\ + \frac{\omega_r q_b}{2} \frac{A}{\sqrt{\epsilon_{\max}}} \sum_{k=0}^{\infty} C_k \sum_{n=-\infty}^{\infty} \sum_{m=-\infty}^{\infty} J_m(Y_-) J_n(Z_-) \cos(\omega_{k,m,n}^- t + \psi_-)$$

Betatron
amplitude

$$\omega_{k,m,n}^{\pm} = (k \pm Q_o) \omega_r + m \Omega_s + n \Omega_{\text{mod}}$$

$$Z_{\pm} = \left(k \pm Q_o \mp \frac{\chi}{\eta} \right) \frac{\Delta \phi_{\text{rf}}}{h}$$


$$Y_{\pm} = \left(k \pm Q_o \mp \frac{\chi}{\eta} \right) \Delta \phi_s$$

- Each synchrotron line of each betatron sideband will have a family of Bessel lines whose spacing is given by the modulation frequency and whose amplitude is given by the modulation amplitude and the chromaticity.

f

Example Phase Modulated Spectrum

Spectrum of a phase modulated signal that has a 25 kHz carrier modulated at rate of 20 Hz with a phase modulation amplitude of 1.75 radians.




Modulation Frequency


- This spectrum would show up at each of the synchrotron sidebands.
- The chromaticity could be determined by measuring the relative amplitudes of the modulation sidebands



Demodulation of a Phase Modulated Signal



Phase Modulation Spectrum




De-modulated Spectrum


- Modern vector signal analyzers can rapidly calculate and display the demodulation spectrum of a phase modulated signal.
- Note that the amplitude of the de-modulated spectrum is independent of the amplitude of the “carrier”
 - The de-modulated spectrum would be independent of the betatron and synchrotron amplitude



TEVATRON Chromaticity Measurements using RF Phase Modulation



Lower Betatron Sideband




Upper Betatron Sideband


- Beam spectra of a single synchrotron line on each of the betatron sidebands
 - ❑ Red is with the RF phase modulation off.
 - ❑ Magenta is with the RF phase modulation on
 - Modulation frequency = 25 Hz
 - Modulation Amplitude = 10 degrees ($\Delta pc/pc = 0.003\%$)
- What a mess!!!!



TEVATRON Chromaticity Measurements using RF Phase Modulation



Lower Betatron Sideband



Upper Betatron Sideband

- Demodulated spectra of the spectra on previous slide
 - Despite the messiness of the original spectra, the demodulated spectra is very clean.
 - The average amplitude can be used to determine the magnitude of the chromaticity
 - The difference of the amplitudes can be used to determine the sign of the chromaticity
- Chromaticity measurements agree quite well with traditional technique



Summary

- The chromaticity can be accurately measured by modulating the RF phase and de-modulating the resulting betatron spectrum.
- The advantages over the present technique
 - Because the measurement is continuous, chromaticity can be measured with a much smaller (10-50x) perturbation to the beam momentum and betatron tune.
 - Technique could be easily implemented during the entire acceleration ramp without having to pause acceleration for the measurement.
- The RF phase modulation measurement technique has not been made operational in the TEVATRON and it remains to be seen whether this technique will become an operationally viable.
- Tune and chromaticity measurements might become more reliable if the beam is coherently excited with a “controlled” signal instead of relying on the “noise” of the TEVATRON to excite the betatron motion.
 - This is the basis of the TEVATRON bunch-by-bunch tune measurement system.